

Firmware Update 15" Photo Display PDJ152



Procedure for firmware update of 15"Photo Display PDJ152

1. Format SD card
 2. Copy the update files on your SD card.
 3. Insert SD card in the 15"Photo Display PDJ152
 4. Restart the Photo Display PDJ152 by switching it on using the ON/OFF slid switch. The upgrading info and process will be shown on the screen. When firmware is upgraded successfully it shows on the screen: "Reboot System".
 5. Pull out the SD card, switch off the PDJ152 and switch it on again.
-



Vorgehensweise für das Firmware Update des 15" Photo Display PDJ152

1. Formatieren Sie eine SD Karte.
2. Kopieren Sie die beide Update Dateien auf die SD Karte
3. Schalten Sie das Gerät am „AN/AUS“ Schiebeschalter aus. Legen Sie die SD Karte mit den Update Dateien ein.
4. Schalten Sie das Gerät ein. Der Update Vorgang beginnt automatisch, dieser wird am Bildschirm dargestellt. Nach erfolgreichem Update erscheint am Bildschirm „Reboot System“; damit fordert Sie Gerät auf neu zu starten.
5. Nehmen Sie nun die SD Karte heraus und starten das Gerät erneut durch den EIN/AUS Schalter.